

Instructions for applying tape to *d*VICE

*display***VICE** [*d***VICE**] can not be considered a 100% iron clad solution to displaying functional wireless products. Expect losses attributed to improper set-up, lack of maintenance and over zealous thieves.

Please read the complete instructions before starting. You need to acquire a general understanding of the set-up process before starting.

I M P O R T A N T - *d***VICE** will be ineffective if the 3M VHB tape is applied improperly or not at all. Please remember to remove the



NOTE: As of December 15, 2004 you will receive *d***VICE** unassembled and with two tape applications on a card. Please follow these instructions to apply the tape. Remember to save the remaining tape for the next application.



1. Remove the *d***VICE** components from the packaging.



2. Remove the tape card from the packaging.



3. Remove the rectangular tape pad from the card.



4. Position the rectangular tape pad on the inside of the first arm and press.


*display***VICE** is a product provided by **RETAIL TASKFORCE** — For any assistance please contact 1-888-826-7773



5. Remove the second rectangular tape pad from the card.



6. Position the rectangular tape pad on the inside of the second arm and press.




7. Remove the capsule tape pad from the card.




8. Align the tape pad with the bottom of the disc.



9. Ensure the straight edges and rounded edges line up. Press the tape against the disc.



10. Remove the semi-circle tape pad from the card.



11. Align the tape pad with the bottom of the security tab.



12. Fold the card with the remaining tape application.



13. Store the card until you need to apply tape again.